

SAN SALVO ECO



Cultivator with 30x30 spiral spring and cage rollers

Pump connected directly to the tractor power take-off (for rubbertyred and crawler tractors)

Kit including multiplier single pump, hoses, filter, tank and oil

Single heat exchanger with double thermostat

Electronic control unit with alarm

65 cm RH side inter-row blade with single-channel joystick for manual emergency blade return

4,5 - 21 - 26 cm ploughshares (to specify during the order)

60 or 100 cm RH lateral expansion with cage roller

Separately mechanical adjustment of rear rollers


RH and LH depth adjustment wheels with bearings

Sled for terrain with stones or superficial roots

Model



CODE



San Salvo ECO 10	0755	60 - 80	10	53	220	20	670
San Salvo ECO 12	0756	60 - 80	12	53	265	20	720



Optional

- CODE 0671 - Hinge and piston for lateral extension hydraulic roll-over with 2 quick tractor couplings for San Salvo and Basic 10-12
- CODE 0723 - Extension protective casing for Basic cultivator
- CODE 0824 - Hydraulic rollers adjustment with 4 quick tractor couplings
- CODE 1335 - Set 10 kit adapters in boron steel complete of reversible chisels and RH and LH laterals fins
- CODE 1337 - Set 12 kit adapters in boron steel complete of reversible chisels and RH and LH laterals fins
- CODE 1052 - RH button for feeler pin deactivation to work with the utensil in the tall grass, to avoid that the feeler pin goes back in when is not necessary (applicable only during the order)
- CODE 0698 - RH hydraulic inter-row inclination with 2 quick tractor couplings. Dimension cm 6,5
- CODE 0942 - Blade with clod breaker, fin and feeler pin cm 55 (additionally to the standard blade)
- CODE 0696 - Blade with clod breaker, fin and feeler pin cm 85 (additionally to standard blade)
- CODE 1160 - RH non-stop feeler pin holder

- CODE 1085 - RH oscillating feeler pin holder adjustable in height

- CODE 1050 - RH stump cleaner for inter-row kit (applicable simultaneously at following inter-row tools: inter-row blade, plant lifting ploughshare, circular cutter, rotary plant lifter and traction disk set)

- CODE 1187 - RH 45 cm inter-row plant lifting ploughshare

- CODE 1268 - RH 55 cm inter-row plant lifting ploughshare

- CODE 1266 - Universal no traction adjustable rounded tiller disc

- CODE 0488 - RH no traction bulldozer-disk diam. 320

- CODE 1264 - Universal no traction adjustable ridger bit disc

- CODE 1312 - Universal no traction adjustable serrated ridger 2-discs complete with cleaner on first disk

[Print this page](#)